





CONTROL AND MAINTENANCE MANUAL: BLINDS UNIVERSAL

1. CONTROL


Chain




Cord / draw bar



Large



Between the glass



DESCRIPTION OF THE CONTROL USING THE CHAIN:

The blind is lifted and lowered using the chain. Drawing is always achieved by one chain in a downward direction.

By drawing both chains at the same time, it can be damaged or can the body of the blind be pulled out from the holders. The tilting of lamellas and regulation of light is performed by fine manipulation with the chain. The lifting height of the lamellas is secured by catching the chain in the holder. For versions of the blind fitted with a brake, the lifted lamellas are held in any position without the need to secure the chain in the holder.

DESCRIPTION OF THE CONTROL USING CORD AND DRAWBAR:

The blind is lifted and lowered using the cord. First of all, release the brake by drawing the cord to the centre of the blind. The blind is lowered by releasing the cord; lifting into the requested position is achieved by drawing in the cord. By drawing the cord into the centre, the consequent release will fix secure the brake.

Tilting of lamellas and regulation of light is achieved by turning the draw bar. Recommendation: when lifting and lowering the blind, tilt the lamellas into the open position.

2. MAINTENANCE

The product does not require any extraordinary maintenance or lubrication of control mechanisms.

In the case of dirtying (dust), regularly use a fine brush or a slightly adjusted manual vacuum cleaner.

During common cleaning, regularly wipe the surface with a cloth or a wet soft textile or sponge. Only use soap solutions without chemical ingredients at a temperature of up to 30°C.

Do not use aggressive detergents, such as organic solvents, cleaning sand, cleaning pastes, developing steams and strong alkali cleaning detergents.


NOTIFICATION:

Ensure careful cleaning of shading lamellas to prevent jamming or other damage.

When cleaning windows, set the product into a position to prevent damage and any interference while cleaning.

Protect the product against dirtying during reconstruction and painting.

3. SAFETY INSTRUCTIONS



Important note

Pursuant to the EN 13 120 standard, we hereby call your attention to possible hazards posed by the use of pull cords and chains!

Safety instructions / strangulation hazard:

- Young children have been strangled by loops in pull-cords, chains and tapes, and cords that operate the product.
- To avoid strangulation and entanglement, keep cords out of the reach of young children. Cords may become wrapped around a child's neck.
- Move beds, cots and furniture away from window covering cords.
Install the enclosed safety components to make sure cords do not twist and create a loop.
- Do not use force when handling with the product if any obstacle prevents its motion.
- Do not attach any items to the product (particularly on the lamellas, control cords, nylon and draw bars).
- Prevent mechanical stress and damage to the product.
- For products controlled by cords, keep cords out of the reach of children to prevent entangling and jamming.
- Handle the product carefully, especially during cleaning.
- Always secure the cord to the two wheels after each use (valid for S, SM, SW)!

NOTES:

- If the product is not functional, contact the seller or the firm which assembled the product.
- The display of the product may slightly differ from the actual version. The producer reserves the right to make changes.
- After the termination of the service life, do not dispose of in communal waste. Materials used can be separated and handed over in accordance with the valid regulations on waste and environmental protection.
Information on waste collection points can be obtained from the local administration office.